


KitchenAid®

Mixer

MODELS:

5KSM55SXXEBM0 (Black Matte)
5KSM55SXXECU0 (Contour Silver)
5KSM55SXXEER0 (Empire Red)
5KSM55SXXEOB0 (Onyx Black)
5KSM55SXXEWH0 (White)


COLOR VARIATION PARTS



COLOR VARIATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing	4		Planetary	6		Column and Pins
	W11123176	Black Matte		W11513622	Black Matte		W11123140	Black Matte
	W10327951	Contour Silver		W11513269	Contour Silver		W10328003	Contour Silver
	9705300	Empire Red		W11513270	Empire Red		9705324	Empire Red
	9705296	Onyx Black		W11513268	Onyx Black		9705320	Onyx Black
	9703311	White		W11513267	White		9703673	White
2		Trim Band	5		Bowl Support and Pins	7		Base & Foot Assembly
	W11420348	Light Brushed Aluminum		W11328664	Black Matte		W11123131	Black Matte
				W10327966	Contour Silver		W10328017	Contour Silver
3		Lower Gearcase		9705360	Empire Red		9705348	Empire Red
	W11520136	Black Matte		9705356	Onyx Black		9705344	Onyx Black
	W11520143	Contour Silver		9703674	White		9703690	White
	W11520142	Empire Red						
	W11421149	Onyx Black						
	W11520144	White						


CASE, GEARING AND PLANETARY UNIT PARTS



CASE, GEARING AND PLANETARY UNIT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Gearcase Motor Housing (Refer to Color Variation Parts Page)	7	W11454895	Gear, Ring and Plate Assembly	15		Planetary Assembly (Refer to Color Variation Parts Page)
			8	3400617	Screw			
			9	3400814	Screw	16		Thumb Screw
2	W11618094	Cap, Attachment Hub	10	W11480076	Motor, 230 Volt Assembly		W11521861	Black
3		Band, Trim (Refer to Color Variation Parts Page)	11	3400200	Screw	17	W11560130	Plate, Lower Housing
4	W10351843	Screw	12	W11509358	Control Assembly (230 Volt)	18	W10419037	Screw
5	9706141	Ring, Attachment Hub	13	W10234531	Pin, Groove			
6		Lower Gearcase (Refer to Color Variation Parts Page)	14		Cord, Power			
				W11459240	Black (EMEA)			

BASE AND PEDESTAL UNIT PARTS



BASE AND PEDESTAL UNIT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Base and Foot Assembly	15		Column Assembly
	W11616370	Use and Care Guide			(Refer to Color Variation Parts Page)			(Refer to Color Variation Parts Page)
2	3400200	Screw			(Refer to Color Variation Parts Page)	16	W11520328	Beater, Flat (Coated)
3	W10717235	Bowl, 5 Quart (Polished)	9	9708649	Foot	17	W11520329	Hook, Dough
4	240185	Pin, Retaining Bowl	10	9703307	Ring, Retaining	18	9706885	Arm, Bowl Lift
5	W10504114	Clip, Bowl Retainer	11	W11376364	Rod, Bowl Lift	19	9703491	Whip, Wire
6	3400018	Screw	12	9237	Spring, Lift Rod	20	9703426	Cam, Adjusting
7		Bowl Support	13	9703439	Washer	21	3400863	Screw
		(Refer to Color Variation Parts Page)	14	8533907	Nut	22	W11376371	Handle, Bowl Lift